

OTC TPMS Version 2.6 Installation Instructions

Note: If you have already installed version 2.5 skip steps 1-4. If you do not have a version 2.5 CD or have misplaced your CD contact OTC service at 1-800-533-6127.

A. Install version 2.5 CD, that came with your kit, onto your PC.

- 1) Place the Version 2.5 CD into the CD drive on your PC. It will self-start in less than a minute. Follow the on-screen install instructions.

B. Authorize the version 2.5 application.

- 2) After the installation is completed, point your web browser to www.otctpms.com.
- 3) Click, **Support** and mouse over to the drop-down menu on the right; click, **Warranty Registration**.
- 4) Click, **Get Manual or CD Activation Code**.
- 5) Follow the on-screen prompts to authorize the version 2.5 application.

C. Download version 2.6 to the desktop of your computer

- 6) Click the www.otctpms.com to return to the home screen. Click, **Support** and mouse over to the drop-down menu on the right; click **Software**; click **Upgrades**.
- 7) Click **2.6 TPMS Update**. This downloads version 2.6 to the desktop of your computer..
- 8) After the file has downloaded to the desktop of your computer, click on the icon labeled **2_6_TPMS_Update.exe**. Installation begins, follow the on-screen prompts.

D. Update your TPMS Tool

- 9) Connect the RS232 cable included with this update kit (Connections look like phone jacks but are larger) into the RS232 port located on the top of your TPMS Tool. Connect the other end of the RS232 cable to the RS232 port on your PC.
Note: *Your PC may be using this port if you are connected to a Local Area Network or broadband internet. Disconnect momentarily to connect your TPMS Tool to your PC.*
- 10) Turn **on** the TPMS tool.
- 11) Click **Update Tool** on the TPMS Tool Main menu.
- 12) Click on the **TPMS Update Icon** located on your computer's desktop.
- 13) Follow the on-screen prompts to update your tool. When the update is completed (less than one minute) a screen will say "Update Complete".